



Item No.	Part No.	Description	Item No.	Part No.	Description
1	BH089628	Aircap Nozzle Needle 1.5mm	11	BH088506	Air Control Assembly
1	BH089630	Aircap Nozzle Needle 1.9mm	12	BD088082	# Air Valve O Ring
1	BH089632	Aircap Nozzle Needle 2.5mm	13	BS088084	# Air Valve O Ring Seat
1	BH089633	Aircap Nozzle Needle 3.5mm	14	BH088165	# Air Valve
3	BH088632	Trigger Pin	15	BA108014	# Air Valve Spring
4	BL089614	Trigger	16	BS088085	# Air Valve Spring Holder
5	BS088450	# Air Valve/Trigger Spacer	17	BD088086	# Air Valve Washer
6	BS088775	# Needle Packing Holder	18	BS088118	Air Valve Seat
7	BA088773	# Needle Packing Spring	19	BI088114	Fluid Control Knob
8	BS088774	# Needle Packing Washer	20	BE088732	# Fluid Inlet O Ring
9	BC088765	# Needle Packing	22	BH138010	Service Kit - items with #
10	BH088494	Fan Control Assembly		BL088057	Metal Pot Ass'y - 1 Litre