

# INSTRUCTION MANUAL

## Spray Gun W-101

### Important

This manual contains IMPORTANT WARNINGS and INSTRUCTIONS. Equipment in this manual is exclusively for painting purposes. Do not use for other purposes. The operator shall be fully conversant with the requirements stated in this instruction manual including important warnings, cautions and operation and correct handling. Read and understand the instruction manual before use and retain for reference.

Be sure to observe warnings and cautions in this instruction manual. If not, it can cause paint ejection and serious bodily injury by drawing organic solvent. Be sure to observe following **▲** marked items which are especially important.

- ▲ WARNING** Indicates a potentially hazardous situation which, if not avoided, may result in serious injury or loss of life.
- ▲ CAUTION** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury or property damage.
- Important** Indicates notes which we ask you to observe. The safety precautions in this instruction manual are the minimum necessary conditions. Follow national and local regulations regarding fire prevention, electricity and safety as well as your own company regulations.

### Important specifications

Max. Pressure	0.68MPa / 6.8 bar / 68 PSI
Noise level	76.7 dB (A)
Spray condition	Recommended
Measuring point	1m backwards from gun, 1.6m height

Max. Temperature	5°C ~ 40°C
Atmosphere	5°C ~ 43°C
Air - Fluid	

### Main specifications

Model	Type of feed	Nozzle orifice φ mm (in)	Air cap Size Mark	Recommended condition				Air & fluid Connection	Mass g (lb)
				%1 Adjusting air pressure MPa (bar / PSI)	Fluid output ml/min	Air consumption l/min (cfm)	Pattern Width mm (in)		
W-101-082P -102P -122P -152P	Pressure	0.8 (0.031)	E2P	0.25 (3.043)	150	270 (9.5)	190 (7.5)	Air G1/4 (NPS1/4)	295 (0.65)
		1.0 (0.039)		200	220 (7.8)	220 (8.7)			
		1.3 (0.051)		250	170 (6.3)	240 (8.4)			
		1.5 (0.059)		300	145 (5.1)	155 (6.1)			
W-101-101S -131S -132S -151S -152S -161S	Suction	1.0 (0.039)	E1	0.24 (2.958)	85	75 (2.6)	120 (4.7)	Air G1/4 (NPS1/4)	295 (0.65)
		1.3 (0.051)		150	145 (5.1)	155 (6.1)			
		1.5 (0.059)		175	145 (5.1)	170 (6.3)			
		1.8 (0.071)		210	170 (6.0)	170 (6.3)			
W-101-101G -131G -132G -151G -152G -161G	Gravity	1.0 (0.039)	E1		85	75 (2.6)	120 (4.7)	Air G1/4 (NPS1/4)	295 (0.65)
		1.3 (0.051)		160	145 (5.1)	170 (6.3)			
		1.5 (0.059)		200	145 (5.1)	170 (6.3)			
		1.8 (0.071)		240	225 (7.9)	190 (7.1)			
W-101-134S※4 -134G※4 -134BPG※4 -142BPG※4 -162BPG※4	Gravity	1.3 (0.051)	H4	0.2 (2.079)	※2. 140	210 (7.4)	※2. 100 (7.1)	Air G1/4 (NPS1/4)	295 (0.65)
		0.24 (2.526)		※3. 145	250 (8.8)	※3. 200 (7.9)			
		0.2 (2.028)		※2. 155	210 (7.4)	※2. 205 (9.1)			
		0.24 (2.526)		※3. 170	250 (8.8)	※3. 220 (8.9)			
W-101-134BPG※4 -142BPG※4 -162BPG※4	Gravity	1.4 (0.055)	H4	0.2 (2.079)	※2. 140	210 (7.4)	※2. 250 (9.0)	Air G1/4 (NPS1/4)	295 (0.65)
		0.24 (2.526)		※3. 145	250 (8.8)	※3. 220 (8.9)			
		0.2 (2.028)		※2. 160	210 (7.4)	※2. 250 (9.0)			
		0.24 (2.526)		※3. 170	250 (8.8)	※3. 220 (8.9)			

※1. Adjusting air pressure means air pressure at gun inlet when trigger is pulled and air flows.  
 ※2. Tested with 12 sec./NK-2 automotive repair paint.  
 ※3. Approximate data on the same condition as other model.  
 ※4. Automotive repair spray gun.  
 ※5. Tested with 40 sec./NK-2 automotive repair paint.

## Safety precautions

### WARNING

#### Fire and explosion

- Spark and open flames are strictly prohibited. Paints can be highly flammable and can cause fire. Avoid any ignition sources such as smoking, open flames, electrical goods, etc.
- Never use the following HALOGENATED HYDROCARBON SOLVENTS which can cause cracks or dissolution on gun body (aluminum) by chemical reaction.
  - unsuitable solvents: methyl chloride, dichloromethane, 1,2-dichloroethane, carbon tetrachloride, trichloroethylene, 1,1,1-trichloroethane
 (Be sure that all fluids and solvents are compatible with gun parts. We are ready to supply a material list used in the product.)
- Securely ground spray gun by using air hose with built-in ground wire. Ground wire: Less than 1MΩ. Check the earth stability periodically. If not, insufficient grounding can cause fire and explosion due to static electric sparking.

#### Improper use of equipment

- Never point gun toward people or animal. If done, it can cause inflammation of eyes and skin or bodily injury.
- Never exceed maximum operating pressure and maximum operating Temperature.
- Be sure to release air and fluid pressures before cleaning, disassembling or servicing. If not, remaining pressure can cause bodily injury due to improper operation or scattering cleaning liquid. In order to release pressure, first stop supply of compressed air, fluid and thinner to spray gun. Then remove trigger toward you.
- Tip of fluid needle set has a sharp point. Do not touch the tip of fluid needle during maintenance for the protection of the human body.

#### Protection of human body

- Use in a well-ventilated site by using spray booth. If not, poor ventilation can cause organic solvent poisoning and catch fire.
- Always wear protective gear (safety glasses, mask, gloves). If not, cleaning liquid, etc. can cause inflammation of eyes and skin. If you feel something wrong with eyes or skin, immediately see a doctor.
- Wear earplugs if necessary.
- Noise level can exceed 80dB(A), depending on operating conditions and painting site. If operators pull the trigger many times during operation, it may cause carpal tunnel syndrome. Be sure to take a rest if you feel tired.

#### Other precautions

- Never alter this spray gun. If done, it can cause insufficient performance and failure.
- Enter working areas of other equipment (robots, reciprocators, etc.) after machines are turned off. If not, contact with them can cause injury.
- Never spray foods or chemicals through this gun. If done, it can cause accident by contact of fluid passages or adversely affect health by mixed foreign matter.
- If something goes wrong, immediately stop operation and find the cause. Do not use again until you have solved the problem.

## How to connect

### CAUTION

-Use clean air filtered through air dryer and air filter. \*\* If not, dirty air can cause painting failure. -If you use this gun for the first time after purchasing, clean fluid passages spraying thinner and remove rust preventive oil. If not, remaining preventive oil can cause painting failure such as fish eyes. -Firmly fit hose or container to spray gun. ... If not, disconnection of hose and drop of container can cause bodily injury.

- Job1. Connect an air hose to air nipple lightly.
- Job2. Connect a fluid hose or a container to fluid nipple lightly.
- Job3. Flush the gun fluid passage with a compatible solvent.
- Job4. Pour paint into container, test spray and adjust fluid output as well as pattern width.

和文取扱は、裏面にあります

CE II 2GX

This Anest-Iwata spray gun kit complies to ATEX regulations 94/9/EC. Protection level II 2GX. Suitable for use in Zones 1 and 2. X marking Any static electricity discharge from the spray gun is to be diverted to the grounded the conductive air hose as stipulated.

## How to operate

Suggested air pressure is 2.0 to 3.5 bar (29 to 50 PSI) for use with Automotive Repair Spray Gun W-101-134/SG-134/BPG-142BPG. Recommended air pressure is 1.5 to 2.5 bar (21 to 36 PSI) and painting conditions. 14 to 25 sec. / Ford output4 is recommended.

Keep fluid output as small as possible to the extent that the job will not be hindered. It will lead to better finishing with fine atomization. Set the spray distance from the gun to the work piece as near as possible within the range of 150-200 mm (5.9-7.9 in).

## Maintenance and inspection

### WARNING

- First release air and pressure fully according to item No. 3 of "Improper use of equipment" of WARNING on page 2.
- Tip of fluid needle set has a sharp point. Do not touch the tip of needle valve at the maintenance for protection of the human body.
- Be careful not to damage the tip of fluid nozzle or insert not put your hand on it.
- Only an experienced person who is fully conversant with the equipment can do maintenance and inspection.

### CAUTION

- Never use commercial or other parts instead of ANEST IWATA original spare parts.
- Never immerse the whole gun into liquid such as thinner.
- Never soak air cap set in solvent for extended period even if cleaning. It may cause defective pattern.
- Never damage holes of air cap a fluid nozzle and fluid needle.

#### Step-by-step procedure

1. Pour remaining paint to another container. Clean fluid passages and air cap set. Spray a small amount of thinner to clean fluid passages.
2. Clean each section with brush soaked with thinner and wipe out with wetted cloth.
3. Disassemble, fully clean fluid passages.
  - (1) Disassemble fluid nozzle. Use ring spanner, box wrench or optional exclusive spanner (code 035396800) to remove fluid nozzle.
  - (2) Disassemble fluid needle set. You do not need to remove fluid set from gun body. Remove fluid set knob and fluid needle spring, and then put out fluid needle set from back of fluid set guide set.
  4. When you want to adjust fluid needle packing set, first tighten it by hand while fluid needle set remains inserted. Then tighten it further about 1/6 turn (30-degree) by spanner. When you remove needle packing set, do not leave paste pieces of needle packing set in the gun body.
5. In order to assemble air valve, first assemble air valve & air valve spring & fluid set guide set together. Next, insert fluid needle set into fluid set guide set, then fit it to gun body set and screw fluid set guide set.
6. Turn pattern set knob or air set knob counterclockwise to fully open. And then lighten pattern set set or air set set.



#### Parts replacement standard

Replace if it is crushed or deformed.

Replace if it is deformed or worn out.

Replace them if leakage does not stop after fully cleaning fluid nozzle and fluid needle set. If you replace fluid nozzle or fluid needle set only, fully match them and confirm that there is no leakage.

## Parts list


When ordering parts, specify gun's model, part name with ref. No. and marked No. of air cap set, fluid nozzle and fluid needle. When replacing fluid nozzle or fluid needle for pressure feed application, please order nozzle needle set.

Fluid nozzle		Fluid nozzle-fluid needle set combination	
Office	Mark	Office	Mark
φ 8.0 (0.31)	W10718	φ 8.0 (0.31)	10008H
φ 1.0 (0.039)	W10710	φ 1.0 (0.039)	10013
φ 1.3 (0.051)	W10713	φ 1.3 (0.051)	10013H
φ 1.4 (0.055)	1078P/34	φ 1.4 (0.055)	10013H
φ 1.5 (0.059)	1078P/42	φ 1.5 (0.059)	10018
φ 1.8 (0.071)	1078P/82	φ 1.8 (0.071)	10018H
φ 1.8 (0.071)	W10718		

## Parts list

No.	Description	Qty.
1	Air cap set	1
2	Fluid nozzle-fluid needle set	1
3	Air valve spring	1
4	Fluid nozzle	1
5	Fluid needle set	1
6	Fluid set guide set	1
7	Fluid set knob	1
8	Air valve shaft	1
9	Air set set	1
10	Trigger stud	1
11	Trigger	1
12	E stopper	1
13	Brush	1
14	Instruction manual	1

◆ Various parts are wearable parts.



## Troubleshooting

Spray Pattern	Problems	Remedies
Fluttering	1. Air enters between fluid nozzle and tapered seat of gun body. 2. Air is drawn from fluid needle packing set. 3. Air enters at fluid container fitting out of fluid hose joint.	1. Remove fluid nozzle to clean seat. If it is damaged, replace nozzle. 2. Tighten fluid needle packing set. 3. Fully tighten part section.
Crackling	1. Paint buildup or damage on fluid nozzle circumference and air cap carrier. 2. Fluid nozzle is not properly fixed.	1. Remove obstructions from horn holes with attached brush. But do not use metal objects to clean horn holes. 2. Replace (if damaged). 3. Remove fluid nozzle and clean seat section.
Inched	1. Paint buildup or damage on fluid nozzle circumference and air cap carrier. 2. Fluid nozzle is not properly fixed.	1. Add paint to increase viscosity. 2. Tighten fluid set knob to reduce fluid output. 3. Turn pattern set valve set clockwise.
Spit	1. Paint viscosity too low. 2. Fluid output too high.	1. Add thinner to reduce viscosity. 2. Turn fluid set valve knob counterclockwise to increase fluid output.
Heavy Center	1. Paint viscosity is too high. 2. Fluid output is too low.	1. Clean or replace fluid nozzle and fluid needle set. 2. Replace fluid nozzle and fluid needle set. 3. Clean air cap set.
Spit	1. Fluid nozzle and fluid needle set are not seated properly. 2. The first stage tray of trigger (when only air discharges) decreases. 3. Paint buildup inside air cap set.	1. Clean or replace fluid nozzle and fluid needle set. 2. Replace fluid nozzle and fluid needle set. 3. Clean air cap set.

Problem	Where it occurred	Parts to be checked	Cause	R1: tighten	R2: adjust	R3: clean	R4: replace parts
Air leaks (from tip of air cap)	Air valve set	Air valve	* Dirt or damage on seat				
		Air valve seat set	* Dirt or damage on seat				
		O ring	* Wear on air valve spring				
		Fluid nozzle ~ fluid needle set	* Damage or deteriorated				
		Fluid nozzle ~ gun body	* Dirt, damage, wear on seat				
		Fluid nozzle ~ packing set	* Loose fluid needle set knob				
		Fluid nozzle ~ needle set	* Insufficient tightening				
		Needle packing set ~ needle set	* Dirt or damage on seat				
		Packing seat	* Needle does not return due to packing set too tight				
		Fluid set knob	* Needle does not return due to paint buildup on fluid needle				
		Tip hole of nozzle	* Wear				
		Paint filter	* Insufficient tightening				
			* Insufficient opening				
			* Chipped				
			* Chipped				

**ANEST IWATA Corporation**  
3176, Shinyoshida-cho, Kohoku-ku, Yokohama, 223-8501, Japan

Manual No. T004-09  
Code No. 03037012